


Washer Quick Start Guide

We know you're excited about owning an ASKO washing machine and you're anxious to get started, so here is a brief summary of the operating procedures. To get the most of the features of your machine, we recommend that you read your *Use and Care Guide*.

THE CONTROL PANEL



Power Button

The Power button turns the power to the machine on and off. When the power is on, the power indicator light glows red. The power must be on before you can open the door, set the programs or start the machine.

Door Open Button

The power must be on and you must press this button to open the door. Please note that the water must be drained before the door will open.

Start/Stop Button

Once you've selected the program and options, press this button to start the washer. To stop the washer during a program, press and hold this button until the indicator light above it goes off.

Option Buttons

The option buttons allow you to select wash temperatures, spin speeds, delayed start, extra rinses, high-water level, and anti-crease. Each option is defined in detail on the next page.

Program Knob

Turn this knob to the desired program (described in the table below). Please note that the knob does not move as the program advances.

Interrupting or Cancelling a Program

To interrupt a program to add an item, press and hold the Door Open button until the indicator light next to the button comes on (about 3 seconds). Any water in the machine will be pumped out and the door will open. When you close the door, the unit will start at the point it was interrupted. To cancel a program, press and hold the Start/Stop button until the indicator light goes off. When you press Start/Stop again, the program will restart from the beginning.

PROGRAMS

Your ASKO washer has several programs and options specifically designed to give you the cleanest laundry possible. The table below shows the recommended types of laundry and load size for each program. Refer to "Options" on the next page for more information.

Program	Types of Laundry	Preset Temps. *	Load Size
Sani	For heavily soiled cotton	140° F	Full
Heavy	For normally soiled cotton	140° F	Full
Normal plus	For lightly soiled cotton and colorfast fabrics	105° F	Full
Perma Press	For acrylic, polyester	140° F	Half
Normal	Lightly soiled fabrics of all types (except wool and acrylics)	140° F	Full
Quick	Lightly soiled fabrics of all types (except wool and acrylics)	105° F	Half
Hand/Wool	Washable	85° F	Third
Delicate	Delicate fabrics, such as silk or nylon	85° F	Third
Rinse			
Spin			
Drain			

* The wash temperatures can be adjusted. See the "Options" section on the following page.

QUICK START PROCEDURES

W6461







1. Press the Power button to turn on the machine.
2. Press the Door Open button to open the inner door and load the wash. (The door will open in a few seconds.)
3. Check that the door is clear of laundry then close it firmly. (The door won't shut if it's slammed.)
4. Pour the detergent and fabric softener into the proper compartments in the detergent drawer, as illustrated below. (Don't put detergent in the prewash compartment unless you plan to prewash.)
5. Close the detergent drawer securely. (Do not slam it closed.)
6. Turn the Program Knob to the desired program and select desired options.
7. Press Start. The machine will start.

UNDERSTANDING THE LED WINDOW

The LED window displays the wash temperature for the selected program, the estimated running time, and the remaining time. It also displays the available options for each program. (See below.) "00" on the LED indicates no program has been selected. "End" indicates the program is complete.

Remaining Time Indication – When you select a program, the LED displays the estimated program time based on the time the program ran previously. As the program progresses, the LED displays the remaining program time. The time is displayed as the hours followed by an "h" and the minutes, e.g., 1h12.

Options

-  **Temperature** Press this button until the temperature you desire displays on the LED. The options are 85°, 105°, 120°, 140°, 160°, 175°, and 205° F. A "C" on the LED indicates the wash temperature will be cold. The Wool and Hand/Delicate programs can only be set for cold, 85° F or 105°F.
-  **Spin Speed** Press this button until the spin speed you desire displays. The spin speeds advance in 200 rpm increments. The minimum spin speed is 400 rpm and the maximum is 1600 rpm. The Perma Press, Wool, and Hand/Delicate programs cannot be set to spin above 800 rpm. You can select No Spin by pressing the button until a zero displays. You can also select No Spin/No Drain by pressing the button until "no d" displays.
-  **Delay** Press this button until the number of hours you wish to delay starting the washer displays on the LED then press Start.
-  **Extra Rinses** Press this button to add two rinses. The indicator light next to the button stays lit when this option is on. Press the button again to turn it off.
-  **High Water** The normal water level for an ASKO is just below the bottom of the glass door. This option is for users who prefer to see the water level. It does not necessarily enhance the washer's performance.
-  **Wrinkle Free** If you are unable to remove the laundry right away, you can reduce wrinkling by selecting this option. The drum will rotate once every minute at the end of the program for two hours or until you press the Door Open button.

NOTE: The unit is programmed to retain the option selections, except for temperatures above 140° F and Delayed Start.

CAUTION! Some fabrics may not be able to withstand extremely hot temperatures. Always refer to the care labels on the garments to be washed for recommended wash temperatures.


THE DETERGENT DRAWER

The detergent drawer on ASKO washers automatically dispenses the detergent and fabric softener at the appropriate times. The drawer is located to the left of the control panel. Simply pull the drawer out and pour the measured amounts of detergent and softener into the proper compartments (as illustrated) and close the drawer.

If you use liquid detergent, you will need to use the main wash compartment partition packaged with your washer. (See your *Use and Care Guide*.)

NOTE: We recommend that you don't use bleach in your ASKO washer.

The tumbling wash action, temperature control options and extended wash times are sufficient to remove most stains.



The detergent drawer is equipped with an optional child safety catch. (See your *Use and Care Guide*.)

DETERGENT AND FABRIC SOFTENER AMOUNTS

Because ASKO washers use less water than conventional top-loading washers, you need less detergent and fabric softener. We recommend that you use a low-sudsing *powder* detergent only, preferably a high-efficiency (HE) detergent designed specifically for front-loading washers. (Liquid detergents tend to suds more, which make them more difficult to rinse out.)

Detergent – The amount of detergent needed varies, depending on the detergent you use. For high-efficiency detergent specifically for front-loading washers, you should use the amounts recommended by the manufacturer. For regular laundry detergent, **1 to 3 tablespoons of detergent is all you need for a normal wash load**. More heavily soiled items, however, may need slightly more detergent. Also, the amount of detergent needed can vary due to differences in water hardness. (Refer to your *Use and Care Guide* for more details.) If you choose to use a liquid detergent, start out with a very small amount, such as one or two tablespoons.

Fabric Softener – We recommend that you use only 2 tablespoons of fabric softener. If more softening is desired, try using slightly more with the next load.

Refer to your *Use and Care Guide* for additional programming and operational information as well as care and cleaning instructions.

Art. No 80 768 15. Rev 01