



Installation instructions for your new

RAVRG1

Access panel with return air grille

Before you begin—Read these instructions completely and carefully.
IMPORTANT—OBSERVE ALL GOVERNING CODES AND ORDINANCES.

Note to Installer—Be sure to leave these instructions with the Consumer.

Note to Consumer—Keep these instructions with your Owner's Manual for future reference.

Tools Needed

- Ruler or tape measure
- Pencil
- Phillips head screwdriver
- Wood saw
- Level

Parts Needed

- 8 Mounting screws (mounting hole dimension $\frac{7}{32}$ ")
- 20" x 20" x 1" Filter

Install the access panel frame with return air grille

IMPORTANT: Access panel must be installed to allow for installation and removal of the vertical zonedline air conditioner.

1. Cut and frame a 28" W x 48" H opening in the closet wall panel.

NOTE: Use a level or suitable method to make sure the cutout is square and plumb. Install the access panel frame in the orientation shown.

2. Remove the four screws from the grille and remove the grille from the frame.
3. Fit the access panel frame into the cutout opening.
4. Secure the access panel frame to the closet wall frame using 8 mounting screws (field supplied). Mounting hole dimensions are $\frac{7}{32}$ ".
5. Install a 20" x 20" x 1" filter (field supplied) in place in the return air grille.
6. Install the grille into the frame and replace the four screws removed earlier.

