

## HOLE PATTERN FOR TABLE MOUNTING VIEWED FROM ABOVE

3

## INSTRUCTIONS FOR SCREW DOWN TABLE TOP MOUNTING:

LOCATE WHERE TV IS TO BE INSTALLED.

NOTE CENTER POSITION OF TV. SCREW HOLES WILL BE
SYMMETRICAL ABOUT CENTER OF TV


MARK 4 SCREW LOCATIONS AT THE DIMENSIONS SHOWN IN THE
SKETCH.


DRILL 4 1/8 INCH DIAMETER HOLES AT THESE LOCATIONS
INSTALL 4 #10 X 1 INCH SCREWS INTO HOLES. TIGHTEN UNTIL
HEAD IS 1/4 INCH ABOVE TABLE TOP SURFACE.
INSTALL TV ONTO SCREWS BY LOWERING THE REAR KEYHOLE
CUTOUTS OVER THE REAR SCREWS AND THEN HOOKING THE
FRONT U-SHAPED HOLE OVER THE HEAD OF THE FRONT
SCREWS AND THEN SLIDING THE TV TOWARDS THE REAR TO
LOCK IN PLACE.
TIGHTEN THE REAR SCREWS TO HOLD THE TV IN PLACE.


TOLERANCES AND DIMENSIONING BEFORE PLATING UNLESS OTHERWISE SPECIFIED:


| DIMENSIONING BEFORE PLATING UNLESS OTHERWISE SPECIFIED:
| DIMENSIONING BEFORE PLATING UNLESS OTHERWISE SPECIFIED:
| DIMENSION IN THE SOLE PROPERTY OF SUNBRITETY LLC. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF SUNBRITETY LLC IS PROHIBITED.


| DIMENSIONING STATE SPECIFIED:
| DRAWN IRW WRITTEN PERMISSION OF SUNBRITETY LLC IS PROHIBITED.
| DRAWN IRW CHECKED IN CHECK























3

4

DRAWN TRW

CHECKED TRW

SCALE: 1:4

09112501\_sb4630 tech drawings

DO NOT SCALE DRAWING DWG. NO.

SHEET 6 OF 7

