

SUMMIT TKW700/SS FILLER TRIM KIT

If your new wall oven is shorter than the cabinet cutout where a previous wall oven of another brand was once installed, you can use the TKW700 or TKW700SS to cover the unused space.

This kit includes:

- (1) Filler Trim
- (4) Screws
- (1) Instruction Sheet

You will need:

- (1) Phillip's Head Screwdriver

Instructions:

1. Locate the filler trim and attachment screws in the kit.
2. Place the filler trim on top of the wall oven and align its mounting slots with the corresponding mounting holes.
3. Attach the filler trim to the wall by driving the mounting screws, but do not tighten them all the way.
4. Adjust the filler trim from left to right as needed so that it is centered over the wall oven's control panel.
5. Tighten the attachment screws.
6. Slide the wall oven into place and complete installation.

