




Frigidaire

Factory Parts Catalog

Product No.	GLEB27S9FBA	GLEB27S9FQA	GLEB27S9FSA
	38256761G6061	38256761G6041	38256761G6011
Series	27" single	27" single	27" single
Color	black	bisque	white
Market	North America	North America	North America
Wiring Diagram	318046235	318046235	318046235
Owner's Guide	318200924	318200924	318200924
Installation Instructions	318201514	318201514	318201514
Service Data Sheet	318047414	318047414	318047414
Timer Guide	318200197	318200197	318200197



Electrolux Major Appliances
North & Latin America
P.O. BOX 212378
AUGUSTA, GA 30917


Publication No.
5995471025
06/07/27
(EN/SERVICE/ECL)
377

SINGLE ELECTRIC WALL OVEN

Model No.
GLEB27S9F

Copyright © 2006 Electrolux Home Products, Inc.
All rights reserved.

CONTROL PANEL




CFEB30S5DSA

CONTROL PANEL

Model Index: **A** GLEB27S9F (GLEB27S9FSA)
 B GLEB27S9F (GLEB27S9FBA)
 C GLEB27S9F (GLEB27S9FQA)

POS. NO	PART NO.		DESCRIPTION
2A	318257301	A B C	Shield, oven top
2B	318260101	A B C	Cover, box
19	318274410	A - -	Control Panel Assembly, glass, white, w/touch pad
19	318274412	- B -	Control Panel Assembly, glass, black, w/touch pad
19	318274411	- - C	Control Panel Assembly, glass, bisque, w/touch pad
20 #	316418721	A B C	Clock/Timer, electronic, ES510W1
*	316021107	A B C	Screw, hex head, 8-32, silver
*	5303211311	A B C	Screw, 8 x 0.500

BODY




BODY

Model Index: **A** GLEB27S9F (GLEB27S9FSA)
B GLEB27S9F (GLEB27S9FBA)
C GLEB27S9F (GLEB27S9FQA)

POS. NO	PART NO.		DESCRIPTION
1	318259212	A B C	Back, main
2	318258910	A B C	Shield, insulation, upper
6	318345210	A B C	Rack, oven, (3)
6A	318219500	A B C	Rack, broiler pan
8	318262011	A B C	Cover, element
8A	318318600	A B C	Bracket, element, hidden bake
9	5303317977	A B C	Pan, broiler
10	5303317976	A B C	Insert, broiler pan
12 #	318089917	A B C	Switch, light
14	318224000	A B C	Receptacle, oven light
14*	318268099	A B C	Insulation, oven light
15	5303013071	A B C	Bulb/Lamp, light
16	08011086	A B C	Lens, oven light, glass
17	5304400195	A B C	Retainer, light cover
29	318147411	A B C	Bumper, (2)
37 #	316217002	A B C	Probe, oven temp
41	5303310526	A B C	Cover, hinge cutout
54	318222400	A B C	Housing, oven light
56	318259902	A - -	Trim, side filler, white, RH
56	318259904	- B -	Trim, side filler, black, RH
56	318259906	- - C	Trim, side filler, bisque, RH
56A	318259903	A - -	Trim, side filler, white, LH
56A	318259905	- B -	Trim, side filler, black, LH
56A	318259907	- - C	Trim, side filler, bisque, LH
58A	318285060	A B C	Insulation, rear & bottom, oven wrapper
58B	318285059	A B C	Insulation, top & sides, oven wrapper
59	318072560	A B C	Duct, oven vent
59A	318261600	A B C	Bracket, vent tube
62	316056000	A B C	Terminal Block
62*	5303323144	A B C	Nut, 10-32
66 #	318255601	A B C	Element, broil, 3400W
67	318254902	A B C	Element, bake, 2700W, 6 pass
68	5304403015	A B C	Support, hanger, (2), broil element
70	318259100	A B C	Shield, insulation, sides, (2)
71	318260001	A B C	Panel, rear box
76	318056222	A B C	Front, oven
80	5303320846	A B C	Plate, oven mtg
81	318192400	A B C	Spring, oven
82	318258710	A B C	Shield, insulation, lower
83	318261500	A B C	Liner, oven assy
86	5303310524	A B C	Receptacle, hinge
87	318260601	A B C	Bracket, cable mtg.
89 #	318261209	A B C	Motor, latch assy
90	318259710	A - -	Trim, oven front, white, bottom
90	318259711	- B -	Trim, oven front, black, bottom
90	318259712	- - C	Trim, oven front, bisque, bottom
99	318256200	A B C	Bracket, side, bottom, (2)
107	318219401	A B C	Cover, fan

BODY




BPLEB27S9DCB

BODY

Model Index: **A** GLEB27S9F (GLEB27S9FSA)
B GLEB27S9F (GLEB27S9FBA)
C GLEB27S9F (GLEB27S9FQA)

POS. NO	PART NO.		DESCRIPTION
108#	318073018	A B C	Motor, blower
*	08016432	A B C	Screw, truss head, 8-18 x 0.375
108A	318251300	A B C	Bracket, fan support
109	316136400	A B C	Blade, fan
111	316136600	A B C	Nut, fan retainer
112#	318112701	A B C	Relay
119#	318004900	A B C	Switch, thermal
125#	316415800	A B C	Motor, fan
125*	5303316994	A B C	Insulation, 3.81 x 3.13
126	318142100	A B C	Washer, motor, RH, convection
127	318317100	A B C	Adapter Assembly, vent tube, w/converter
131	318272900	A B C	Box, vent
132	318003000	A B C	Plate, shield
142	318123910	A B C	Deflector
*	5303324184	A B C	Screw, 8-18 x 5/16, black, (4)
143	318172904	A B C	Support, wire
161#	318255503	A B C	Element, convection, 350 W
163	318014111	A B C	Spacer
185	318014700	A B C	Spacer, oven shield, (4)
219#	318003614	A B C	Thermostat, safety
219A	318003613	A B C	Thermostat, safety, 1.375" mtg, 105/120
263	316136500	A B C	Washer, flat
264	318257711	A B C	Trim, oven, black, front
272	318249401	A B C	Tube, protector
310	5304440067	A B C	Cabinet Mounting Kit
311	318246010	A B C	Bracket, cabinet mtg, (2)
311*	5304438005	A B C	Screw, 6 x 1, black
312	318246702	A B C	Tool, cabinet bracket, RH
312	318246703	A B C	Tool, cabinet bracket, LH
* #	318078542	A B C	Box & wires assy
*	318231737	A B C	Harness, wiring, main
*	5303323136	A B C	Screw ground
*	318165800	A B C	Spacer
*	3201861	A B C	Screw, 6 x 0.375, (4)
*	5303211311	A B C	Screw, 8 x 0.500
*	5303323139	A B C	Screw, 10-24 x 0.906
*	5303323277	A B C	Screw, 8-18 X 13/32
*	5304436875	A B C	Screw, 8-18 X 1/2, black

DOOR




DGLEB30S9FSA

DOOR

Model Index: **A** GLEB27S9F (GLEB27S9FSA)
B GLEB27S9F (GLEB27S9FBA)
C GLEB27S9F (GLEB27S9FQA)

POS. NO	PART NO.		DESCRIPTION
3	318260211	A B C	Trim, oven door, black, upper
3A	318260401	A B C	Trim, oven door, side, (2)
4	318261351	A - -	Glass Assy., oven door, white, outer, w/trim
4	318261350	- B -	Glass Assy., oven door, black, outer, w/trim
4	318261352	- - C	Glass Assy., oven door, bisque, outer, w/trim
6	318260510	A B C	Baffle, door
7	318285057	A B C	Insulation, oven door
7A	318285061	A B C	Insulation, (2)
8	318212200	A B C	Glass, oven door, heat barrier
9	318259611	A B C	Liner, oven door, upper
10	316001002	A B C	Screw, wafer head, 10-24 x 1.81, (2), handle mtg.
12	318053135	A B C	Seal, oven door
17	318264700	A B C	Spacer, glass, (2)
23	318024724	A B C	Hinge, door, (2)
29	318014402	A B C	Spacer, door
39	5304457046	A - -	Handle, door, white, w/spacer
39	5304457045	- B -	Handle, door, black, w/spacer
39	5304457047	- - C	Handle, door, bisque, w/spacer
40	318242700	A B C	Bracket, glass holder, (2)
56	5304436875	A B C	Screw, 8-18 X 1/2, black
64	318165800	A B C	Spacer
*	08016432	A B C	Screw, truss head, 8-18 x 0.375
*	5303211311	A B C	Screw, 8 x 0.500
*	5303300265	A B C	Screw, 8-18 X 1/2, (2)
*	5303323277	A B C	Screw, 8-18 X 13/32

WIRING DIAGRAM



COLORS / COLOR / COULEURS


BK- BLACK/NEGRO/NOIR
 W- WHITE/BLANCO/BLANC
 O- ORANGE/NARANJA/ORANGE
 BR- BROWN/MORENO/BRUN
 PK- PINK/ROSA/ROSE
 V- VIOLET/VIOLETA/VIOLET
 G- GREEN/VERDE/VERT
 R- RED/ROJO/ROUGE
 Y- YELLOW/AMARILLO/JAUNE
 BL- BLUE/AZUL/BLEU
 BR/W- BROWN/WHITE // MORENO/BLANC // BRUN/BLANC
 BL/W- BLUE/WHITE // AZUL/BLANC // BLEU/BLANC

CODE/CODIGO/CODE


CODE	GAUGE/MED. CALIBRE	TEMP. °C	CSA	STYLE	UL
1	18	125	CL-1251		3173
2	16	125	CL-1251		3173
3	14	125	CL-1251		3173
4	12	125	CL-1251		3173
5	18	150	EXL-150		3321
6	16	150	EXL-150		3321
7	14	150	EXL-150		3321
8	12	150	EXL-150		3321
9	10	150	EXL-150		3321
10	18	200	SEW-1		3122
11	16	200	SEW-1		3122
12	12	250			3252
13	16	250			3252
14	20	150	EXL-150		3321
15	8	150	EXL-150		3321
16	8	60			
17	10	60			

EXAMPLE/EJEMPLO/EXAMPLE: (R-81)*

- * WHEN USING 4000 W. BROIL ELEMENT
- * CUANDO SE USA 4000 W. ELEMENTO DE ASADO
- * QUAND UTILISE AVEC 4000 W. ELEMENT GRILLAGE



SW. A
 MOTOR LATCH SW.
 INTER. DE MOTOR DE CERRAJEO
 INTER. MOTEUR VERROU



CAUTION: DISCONNECT POWER BEFORE SERVICING UNIT.
 ATENCION: CORTAR EL CORRIENTE ANTES DE REALIZAR EL MANTENIMIENTO DEL ELECTRODOMESTICO.
 ATTENTION: COUPEZ L'ALIMENTATION AVANT D'EFFECTUER LA REPARATION.

318046235 REV:A