




*Frigidaire*

## Factory Parts Catalog

| Product No.               | FGC36C4AUC    | FGC36C4AWC    |
|---------------------------|---------------|---------------|
|                           | 3775441161043 | 3775441161013 |
| Series                    | 36" gas       | 36" gas       |
| Color                     | black/bisque  | black/white   |
| Market                    | North America | North America |
| Wiring Diagram            | 318047111     | 318047111     |
| Owner's Guide             | 318200658     | 318200658     |
| Installation Instructions | 318201452     | 318201452     |

 **Electrolux**

ELECTROLUX HOME PRODUCTS, INC.  
P.O. Box 212378, Augusta, GA 30917


Publication No.  
**5995423570**  
04/12/06  
(EN/SERVICE/ECL)  
377

## GAS COOK-TOP RANGE

Model No.  
**FGC36C4A**

Copyright © 2004 Electrolux Home Products, Inc.  
All rights reserved.

# COOK TOP




LA00CT77411-1B

**COOK TOP**

*Model Index:*    **A** FGC36C4A (FGC36C4AWC)  
                               **B** FGC36C4A (FGC36C4AUC)

| <b>POS. NO</b> | <b>PART NO.</b> |     | <b>DESCRIPTION</b>       |
|----------------|-----------------|-----|--------------------------|
| 16             | 318159311       | A - | Main Top, white          |
| 16             | 318159314       | - B | Main Top, bisque         |
| 18             | 318074310       | A B | Hinge, maintop, (2)      |
| 19             | 318067300       | A B | Pan, burner, (4)         |
| 20             | 316040807       | A B | Grate, black, (4)        |
| 23             | 318242400       | A B | Panel, control, black    |
| 42             | 5303311316      | A B | Trim, vent, front        |
| 43             | 318196150       | A B | Knob, control, black     |
| 45A            | 3201437         | A B | Strain relief            |
| 46             | 318077113       | A B | Burner Box               |
| 47             | 318144002       | A B | Cord, service            |
|                |                 |     |                          |
| *              | 5303311306      | A B | Screw, 8-18 x 0.375      |
| *              | 5303311333      | A B | Screw, 8-32 x 3/8, (6)   |
| *              | 5303311532      | A B | Screw, 6-32 x 1/4", back |

BURNER



NOTE: Top burner valves  
include mounting screw.

LA00BR77411-2

**BURNER**

Model Index:   **A** FGC36C4A (FGC36C4AWC)  
                       **B** FGC36C4A (FGC36C4AUC)

| POS. NO | PART NO.   |     | DESCRIPTION                     |
|---------|------------|-----|---------------------------------|
| 1       | 318177102  | A B | Manifold Pipe                   |
| 2 #     | 318087012  | A B | Valve, top burner               |
| 2*      | 5303323141 | A B | Screw, valve mtg, 1/4-20 x 5/16 |
| 3 #     | 318232609  | A B | Wiring Harness, w/igntr switch  |
| 8 #     | 316135700  | A B | Module, spark                   |
| 8*      | 318024201  | A B | Bracket, spark module           |
| 10 #    | 318176412  | A B | Burner, top, LF & RR            |
| 10A#    | 318176413  | A B | Burner, top, RF & LR            |
| 11 #    | 318148503  | A B | Ignitor, top burner             |
| 12      | 3016993    | A B | Retainer, ignitor               |
| 14 #    | 5308007974 | A B | Regulator, pressure             |
| 33      | 5303311317 | A B | Bracket, burner mtg, (2)        |
| 35      | 318146300  | A B | Bushing                         |
|         |            |     |                                 |
| *       | 5303324191 | A B | Washer, flat                    |
| *       | 08016432   | A B | Screw, truss head, 8-18 x 0.375 |
| *       | 5303311306 | A B | Screw, 8-18 x 0.375             |
| *       | 5303311532 | A B | Screw, 6-32 x 1/4", back        |

WIRING DIAGRAM

