



Frigidaire

Factory Parts Catalog

Product No.	FEB30S5DBA	FEB30S5DSA
	38254331E4061	38254331E4011
Series	30" single	30" single
Color	black	white
Market	North America	North America
Wiring Diagram	318046227	318046227
Owner's Guide	318200924	318200924
Installation Instructions	316201514	316201514
Service Data Sheet	316047413	316047413
Timer Guide	318200189	318200189

 **Electrolux**

ELECTROLUX HOME PRODUCTS, INC.
P.O. Box 212378, Augusta, GA 30917


Publication No.
5995418166
04/10/07
(EN/SERVICE/ECL)
377

**SINGLE ELECTRIC
WALL OVEN**

Model No.
FEB30S5D

Copyright © 2004 Electrolux Home Products, Inc.
All rights reserved.

CONTROL PANEL




CFEB30S5DSA

CONTROL PANEL

Model Index: A FEB30S5D (FEB30S5DSA)
 B FEB30S5D (FEB30S5DBA)

POS. NO	PART NO.		DESCRIPTION
2A	318257300	A B	Shield, oven top
2B	318260100	A B	Cover, box
19	318274600	A -	Control Panel Assembly, glass, white, w/ touch pad
19	318274601	- B	Control Panel Assembly, glass, black, w/ touch pad
20 #	316418522	A B	Clock/Timer, electronic, ES350W1
*	316021107	A B	Screw, hex head, 8-32, silver
*	5303211311	A B	Screw, 8 x 0.500

BODY




BFEB30S5DSA

BODY

Model Index: A FEB30S5D (FEB30S5DSA)
B FEB30S5D (FEB30S5DBA)

POS. NO	PART NO.		DESCRIPTION
1	318259200	A B	Back, main
2	318258900	A B	Shield, insulation, upper
6	318262502	A B	Rack, oven
9	5303317977	A B	Pan, broiler
10	5303317976	A B	Insert, broiler pan
12 #	318089917	A B	Switch, light
*	3015722	A B	Clip, wire retainer
14	318224000	A B	Receptacle, oven light
14*	318268099	A B	Insulation, oven light
15	5303013071	A B	Bulb/Lamp, oven light
16	3201911	A B	Cover, oven light, glass
17	5304400195	A B	Retainer, light cover
29	318147411	A B	Bumper, door, (2)
37 #	316217002	A B	Probe, oven temp
41	5303310526	A B	Cover, hinge cutout
54	318222400	A B	Housing, oven light
56	318259902	A -	Trim, side filler, white, RH
56	318259904	- B	Trim, side filler, black, RH
56A	318259903	A -	Trim, side filler, white, LH
56A	318259905	- B	Trim, side filler, black, LH
58A	318133791	A B	Insulation, oven wrapper, back/bottom
58B	318133790	A B	Insulation, oven wrapper, top/sides
58D	318133793	A B	Insulation, 1/2" thick, 43 x 9.5
59	318072560	A B	Duct, oven vent
59A	318261600	A B	Bracket, vent tube
62	316056000	A B	Terminal Block
62*	5303323144	A B	Nut, 10-32
66 #	318255600	A B	Element, broil, 2750W
67 #	318255401	A B	Element, bake, 3400W
68	5304403015	A B	Support, element hanger
70	318259100	A B	Shield, insulation, sides, (2)
71	318260004	A B	Panel, rear box
76	318056217	A B	Front, oven
80	5303320846	A B	Plate, oven mtg
81	318192400	A B	Spring, oven
82	318258700	A B	Shield, insulation, lower
83	318261403	A B	Liner, oven assy
86	5303310524	A B	Receptacle, hinge
87	318260602	A B	Bracket, cable mtg.
89#	318261200	A B	Motor, latch assy
90	318259700	A -	Trim, oven front, white, bottom
90	318259701	- B	Trim, oven front, black, bottom
99	318256200	A B	Bracket, side, bottom, (2)
108#	318073018	A B	Motor, blower
*	08016432	A B	Screw, truss head, 8-18 x 0.375
108A	318251300	A B	Bracket, fan support
112#	318112701	A B	Relay
119#	318004900	A B	Switch, thermal
127	5303310542	A B	Adapter, vent tube, with converter

BODY




BFEB30S5DSA

BODY

Model Index: A FEB30S5D (FEB30S5DSA)
B FEB30S5D (FEB30S5DBA)

POS. NO	PART NO.		DESCRIPTION
131	318272900	A B	Box, vent
132	318003000	A B	Plate, shield
142	318123910	A B	Deflector
*	5303324184	A B	Screw, 8-18 x 5/16, black, (4)
143	318172904	A B	Support, wire/glass
163	318014111	A B	Spacer
185	318014700	A B	Spacer, oven shield, (4)
219#	318003606	A B	Thermostat, safety
219A	318003613	A B	Thermostat, safety
264	318257701	A B	Trim, oven, black, front
310	5304440067	A B	Cabinet Mounting Kit
311	318246010	A B	Bracket, cabinet mtg, (2)
311*	5304438005	A B	Screw, 6 x 1, black
312	318246702	A B	Tool, cabinet bracket, RH
312	318246703	A B	Tool, cabinet bracket, LH
* #	318078542	A B	Box & wires assy
*	318231719	A B	Harness, wiring, main
*	3201861	A B	Screw, 6 x 0.375, (4)
*	5303211311	A B	Screw, 8 x 0.500
*	5303323136	A B	Screw ground
*	5303323139	A B	Screw, 10-24 x 0.906
*	5303323277	A B	Screw (8-18X13/32)
*	5304436875	A B	Screw, 8-18 X 1/2, black

DOOR



DFEB30S5DSA

DOOR

Model Index: A FEB30S5D (FEB30S5DSA)
 B FEB30S5D (FEB30S5DBA)

POS. NO	PART NO.		DESCRIPTION
3	318260201	A B	Trim, oven door, black, upper
3A	318260401	A B	Trim, oven door, side, (2)
4	318261301	A -	Glass Assy., oven door, white, outer, w/ trim
4	318261300	- B	Glass Assy., oven door, black, outer, w/ trim
6	318260500	A B	Baffle, door
7	318133792	A B	Insulation, oven door
7A	318133797	A B	Insulation, oven door, cavity
8	316117500	A B	Glass, oven door, heat barrier
9	318259601	A B	Liner, oven door
10	5304416408	A B	Screw, 10-24 x 1.750, handle mtg
12	318053120	A B	Seal, oven door
17	316402403	A B	Spacer, door glass, (2)
23	5303310828	A B	Hinge, oven door, (2)
29	318014402	A B	Spacer, door
39	316203001	A -	Handle, door, white
39	318231200	- B	Handle, black
40	318242700	A B	Bracket, glass holder, (2)
56	5304436875	A B	Screw, 8-18 X 1/2, black
64	318165800	A B	Spacer, (4)
*	08016432	A B	Screw, truss head, 8-18 x 0.375
*	5303211311	A B	Screw, 8 x 0.500
*	5303300265	A B	Screw, 8-18 x 0.500, chrome, (3)
*	5303323277	A B	Screw (8-18X13/32)

WIRING DIAGRAM

