




Frigidaire

Factory Parts Catalog

Product No.	FGC30S4DBA
	3775421264061
Series	30" gas
Color	black
Market	North America
Wiring Diagram	318047111
Owner's Guide	318200657
Installation Instructions	318201451

 **Electrolux**

ELECTROLUX HOME PRODUCTS, INC.
P.O. Box 212378, Augusta, GA 30917


Publication No.
5995424388
04/12/15
(EN/SERVICE/ECL)
377

GAS COOK-TOP RANGE

Model No.
FGC30S4D

Copyright © 2004 Electrolux Home Products, Inc.
All rights reserved.


COOK TOP



LA9922T15

COOK TOP

POS. NO	PART NO.	DESCRIPTION
16	318159144	Panel, main top, black
19	318167903	Pan, burner, medium, black
19A	318167904	Pan, burner, large, black
19B	318167905	Pan, burner, small, black
20	318227002	Grate, burner, black, (4)
22	318076410	Cap, burner, black, medium LF & LR
22A	318076420	Cap, burner, black, large RF
22B	318076400	Cap, burner, black, small RR
23	318242314	Panel, control, black
43	318196141	Knob, control, black
46	318156000	Burner Box
47	318144002	Cord, service
64	5303304033	Bracket, retainer
65	5303304032	Seal, rubber
132	3201437	Strain relief
136	5303935029	Support
137	5303285443	Screw, lock bracket, 10-24 x 2.00
*	5303307980	Screw, 8-32 x 0.437


BURNER

LA00BR77490-1

BURNER

POS. NO	PART NO.	DESCRIPTION
1	318177003	Manifold Pipe
2 #	318087040	Valve, top burner, 13000 BTU
2A #	318087001	Valve, top burner, 5000 BTU
2B #	5303935042	Valve, top burner, 2-position, 9100 BTU
3 #	318232604	Wiring Harness, w/igntr switch
4 #	318167714	Tube, burner, RF
5 #	318167700	Tube, burner, LF
6 #	318167702	Tube, burner, RR
7 #	318167701	Tube, burner, LR
8 #	316135701	Module, spark
8*	318024200	Bracket, spark module
10 #	318148001	Burner, top, 9100 BTU, medium LF & LR
10A#	318148002	Burner, top, 13000 BTU, large RF
10B#	318148000	Burner, top, 5000 BTU, small RR
14 #	5308007974	Regulator, pressure
35	318146300	Bushing
72	5303323141	Screw, valve mtg, 1/4-20 x 5/16
73	318024201	Bracket, spark module
74 #	318148700	Ignitor, top burner
75	318148800	Clip, electrode
76 #	318167801	Tube, mixing, medium & large
76A#	318167800	Tube, mixing, small
77	318112010	Bracket, burner mtg, medium & large
77A	318112000	Bracket, burner mtg, small
77B	318180900	Bracket, burner tube
78	318220100	Shield, burner box
* #	318127407	LP Conversion Kit
*	318199729	Wiring Harness, ignitor
*	08011955	Screw, 10-24 x 0.375, square drive
*	5303311532	Screw, 6-32 x 1/4", back
*	5304403558	Screw, 10-16 x 0.250

WIRING DIAGRAM



318047111 REV. A