



LENGTH OF WARRANTY:	KITCHENAID WILL PAY FOR:	KITCHENAID WILL NOT PAY FOR:
ONE-YEAR FULL WARRANTY FROM DATE OF PURCHASE.	Replacement parts and repair labor costs to correct defects in materials or workmanship. Service must be provided by a KitchenAid designated service company.	<ul> <li>A. Service calls to: <ol> <li>Correct the installation of the cooktop.</li> <li>Instruct you how to use the cooktop.</li> <li>Replace house fuses or correct house wiring.</li> <li>Correct house plumbing.</li> </ol> </li> <li>B. Repairs when cooktop is used in other than normal home use.</li> </ul>
SECOND- THROUGH FIFTH- YEAR LIMITED WARRANTY FROM DATE OF PURCHASE.	Replacement parts for any gas burner to correct defects in materials or workmanship.	C. Damage resulting from accident, alteration, misuse, abuse, fire, flood, acts of God, improper installation, or installation not in accordance with local electrical or plumbing codes.      D. Any labor costs during the limited warranties.
		E. Replacement parts or repair labor costs for units operated outside the United States and Canada.
		F. Pickup and delivery. This product is designed to be repaired in the home.
		<b>G.</b> Repairs to ceramic glass cooktop if it has not been cared for as recommended in this Use and Care Guide.
		Repairs to parts or systems resulting from unauthorized modifications made to the appliance.
		In Canada, travel or transportation expenses for customers who reside in remote areas.  9/99

KITCHENAID AND KITCHENAID CANADA DO NOT ASSUME ANY RESPONSIBILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES. Some states or provinces do not allow the exclusion or limitation of incidental or consequential damages, so this exclusion or limitation may not apply to you. This warranty gives specific legal rights and you may also have other rights which vary from state to state or province to province.

Outside the United States and Canada, a different warranty may apply. For details, please contact your authorized KitchenAid dealer.

If you need assistance or service, first see the "Troubleshooting" section in this book. After checking "Troubleshooting," additional help can be found by checking the "Requesting Assistance or Service" section. In the U.S.A., call our Consumer Assistance Center at 1-800-422-1230. In Canada, call KitchenAid Canada at one of the telephone numbers listed in the "Requesting Assistance or Service" section.