



Frigidaire

Factory Parts Catalog

Product No.	GLMB209DBB	GLMB209DQB	GLMB209DSB	PLMB209DCC
Market	North America	North America	North America	North America
Color	black	bisque	white	stainless steel
Volts	120	120	120	120
Watts	1200	1200	1200	1200
Wiring Diagram	5995456752	5995456752	5995456752	5995456752
Owner's Guide	316137232	316137232	316137232	316137232
Installation Instructions	316137335	316137335	316137335	316137335



Electrolux Major Appliances
North & Latin America
P.O. BOX 212378
AUGUSTA, GA 30917


Publication No.
5995456752
06/01/06
(EN/SERVICE/KC)
099

COUNTER-TOP MICROWAVE

Model No.
GLMB209D / PLMB209D

Copyright © 2005 Electrolux Home Products, Inc.
All rights reserved.

OVEN,CABINET




GLMB209DB Cabinet

OVEN,CABINET

Model Index: **A** GLMB209D (GLMB209DBB)
B GLMB209D (GLMB209DQB)
C GLMB209D (GLMB209DSB)
D PLMB209D (PLMB209DCC)

POS. NO	PART NO.	DESCRIPTION			
1 #	5304440777	A	B	C	D
2 #	5304440778	A	B	C	D
3 #	5304440779	A	B	C	D
4 #	5304448490	A	B	C	D
5 #	5303319559	A	B	C	D
6 #	5304440026	A	B	C	D
7 #	5304440780	A	B	C	D
8 #	5304440781	A	B	C	D
9 #	5304448832	A	B	C	D
10 #	5304440783	A	B	C	D
11 #	5304440784	A	B	C	D
12 #	5304440785	A	B	C	D
13	5304440814	A	B	C	D
14	5304440815	A	B	C	D
15	5304440816	A	-	-	D
15	5304440818	-	B	-	-
15	5304440817	-	-	C	-
28	5304440838	A	B	C	D
29	5304440839	A	B	C	D
30	5304440840	A	B	C	D
31	5304440841	A	B	C	D
32	5304440842	A	B	C	D
33 #	5304440843	A	B	C	D
34	5304440844	A	B	C	D
35 #	5304451818	A	B	C	D
36	5304440845	A	B	C	D
37	5304440288	A	B	C	D
38	5304441909	A	B	C	D
39	5304440847	A	B	C	D
40	5304441910	A	B	C	D
53	5304440284	A	B	C	D
54	5304440868	A	B	C	D
55	5304440334	A	B	C	D
56	5304440333	A	B	C	D
59	5303319636	A	B	C	D
60	5303319641	A	B	C	D
61	5304440871	A	B	C	D
63	5303319633	A	B	C	D
64	5304440872	A	B	C	D
65	5304440873	A	B	C	D
66	5304440874	A	B	C	D
67	5304441963	A	-	-	-
67	5304440340	-	B	C	D
69	5303322975	A	B	C	D
70 #	5303319550	A	B	C	D

CONTROL PANEL,DOOR,MISC.



DOOR PARTS


MISCELLANEOUS

GLMB209D controls

CONTROL PANEL,DOOR,MISC.

Model Index: **A** GLMB209D (GLMB209DBB)
B GLMB209D (GLMB209DQB)
C GLMB209D (GLMB209DSB)
D PLMB209D (PLMB209DCC)

POS. NO	PART NO.		DESCRIPTION
16 #	5304440820	A B C D	Control Board, printed circuit
17	5304442129	A - - -	Frame, control panel, black
17	5304440823	- B - -	Frame, control panel, bisque
17	5304440822	- - C -	Frame, control panel, white
17	5304440821	- - - D	Frame, control panel, black
18 #	5304440824	A - - D	Switch Assy, touch control, black
18 #	5304440826	- B - -	Switch Assy, touch control, bisque
18 #	5304440825	- - C -	Switch Assy, touch control, white
19	5304440827	A - - -	Push Button, door opener, black
19	5304440829	- B - -	Push Button, door opener, bisque
19	5304440828	- - C -	Push Button, door opener, white
19	5304448833	- - - D	Push Button, door opener, stainless steel
20	5304440831	A B C D	Spring, door button
21	5304440282	A B C D	Screw, control board, 3mm x 10mm
22	5304440832	A B C D	Connector, rubber, control board
23	5304440833	A B C D	Panel, touch pad mount
24 #	5304440834	A B C D	LED Sheet, backlight
25 #	5304440835	A B C D	LCD, display
26	5304440836	A B C D	Bracket, PCB support
27	5304448834	- - - D	Trim, control panel, stainless steel, deco plate
41	5304440848	A - - -	Door Assy, complete, black
41	5304440850	- B - -	Door Assy, complete, bisque
41	5304440849	- - C -	Door Assy, complete, white
41	5304448835	- - - D	Door Assy, complete, stainless steel, with handle
42	5304440852	A - - -	Panel Assy, outer door, black, with latch
42	5304440854	- B - -	Panel Assy, outer door, bisque, with latch
42	5304440853	- - C -	Panel Assy, outer door, white, with latch
42	5304448836	- - - D	Panel Assy, outer door, stainless steel, with latch
43	5304440856	A B C D	Latch, door
44	5304440316	A B C D	Spring, door latch
45	5304440857	A - - D	Panel, inner door, black
45	5304440859	- B - -	Panel, inner door, bisque
45	5304440858	- - C -	Panel, inner door, white
46	5304440860	A B C D	Seal, door, film
47	5304440861	A B C D	Frame, choke cover, inner door
48	5304442145	A B C D	Door Stop
49	5304440863	A - - D	Panel, glass, black, door front
49	5304440865	- B - -	Panel, glass, bisque, door front
49	5304440864	- - C -	Panel, glass, white, door front
50	5304440862	A B C D	Door Stop
51	5304440866	A B C D	Screw
52 #	5304452260	A B C D	Wiring Harness, main
58 #	5304440870	A B C D	Wire, high voltage-A

WIRING SCHEMATIC

Note: * Indicates component




Figure O-1 Oven Schematic - Off Condition





Figure O-2 Oven Schematic - Cooking Condition