

Frigidaire

Factory Parts Catalog

Product No.	FGF303CWE
Series	30" f/s gas
Color	black/white
Market	North America
Wiring Diagram	316255203
Owner's Guide	316257510
Installation Instructions	316259327

 **Electrolux**

Electrolux Major Appliances
North & Latin America
P.O. BOX 212378
AUGUSTA, GA 30917


Publication No.
5995460242
06/02/06
(EN/SERVICE/ECL)
369

**30-INCH FREE-
STANDING GAS
RANGE**

**Model No.
FGF303C**

Copyright © 2006 Electrolux Home Products, Inc.
All rights reserved.

BACKGUARD




L24G0030

BACKGUARD

POS. NO	PART NO.	DESCRIPTION
12 #	316032404	Thermostat
12*	316097602	Insulator
18	316263900	Bracket, backguard
32	316102300	Knob, thermostat, black
36	316009008	Knob, top valve, black, (4)
40	316458006	Panel, manifold, black
49	316263802	Panel, backguard, white
*	316021105	Screw, hex head cup pt, 8-18 x 0.375, black
*	316021108	Screw, cup pt, 8-18 x 0.375, chrome
*	316021110	Screw, 8-18 x 0.5, black

BURNER




L24B0003

BURNER

POS. NO	PART NO.	DESCRIPTION
1 #	316269100	Pipe, manifold
2 #	5303935237	Valve, top burner, w/mtg screw
*	316215600	Screw, valve mtg., 1/4 - 20
3	316001828	Wiring Harness, ignitor, with switches
8 #	316135700	Module, spark
10 #	316103800	Burner, top, front, venturi ring
10A#	316103801	Burner, top, rear, venturi ring
11A#	316081705	Ignitor, top burner, 50"
12	3016993	Retainer, ignitor
14 #	316091705	Regulator, pressure
14*	316021104	Screw, hex, 8-18 x 3/8, nick, (3), regulator brkt
17 #	3203459	Valve, safety
18 #	316114300	Burner, oven
19 #	5303935066	Ignitor, oven kit, w/nut & instr
20	3203265	Baffle, oven burner
21	5303013272	Nut, hex head sems
36	316065004	Tubing, 3/8, alum
48	3018603	Bracket, support, oven burner
49	3131438	Bracket, safety valve
*	5303271648	Screw, wafer hd sq dr, 8-18AB x 0.5

BODY



NOTE: Oven Liner N/A
Ass. du four N/A

T24V0057


BODY

POS. NO	PART NO.	DESCRIPTION
1	316029415	Panel, main back
3	316400116	Panel, bodyside, white, RH
3	316400117	Panel, bodyside, white, LH
4	316067210	Burner Box
5	316129100	Fastener, push-in nut, nylon, spacer
5A	316407201	Leveling Leg Assy, metal, front, (2), bracket & leg
6	316067902	Rack, oven
7	316216502	Hinge, oven door, RH
7A	316216503	Hinge, oven door, LH
8	5303300701	Panel, oven bottom
8*	316064600	Support, oven bottom
9	316081900	Pan, broiler
10	316082000	Insert, broiler pan
27	5303284616	Clip, thermo bulb mtg
32	316107501	Channel, burner support
32*	5303289684	Fastener, tanden wire, (2)
34	3018607	Plate, cover
35	316116600	Gasket, flue
36	316204401	Flue, black
39	3202006	Cord, electric power
41	316233400	Cover, hinge cutout, RH
41A	316233500	Cover, hinge cutout, LH
43	3131732	Screw, 8-18 x 1.438, oven bottom
58A	3017142	Insulation, oven wrapper
58B	316054202	Insulation, 1", oven back
69	3051218	Plate, oven light
73	316109902	Base, low broil
93	316110000	Shield, ignitor, metal
170	5303935180	Anti-tip Kit, w/bracket, screw
170*	316107200	Bracket, anti-tip
170*	316112500	Template, anti-tip
170*	316116000	Screw, concrete, 1.75", anti-tip brkt
185	316112900	Shield, thermo bulb
* #	316001208	Wiring Harness, main
*	316246400	Plug, button, oven probe
*	316435800	Plate, weight, (3)
*	5303321319	Paint, touch-up, white
*	5303305345	Paint, touch-up, black
*	316021105	Screw, hex head cup pt, 8-18 x 0.375, black
*	316021108	Screw, cup pt, 8-18 x 0.375, chrome
*	316021110	Screw, 8-18 x 0.5, black
*	316089500	Screw, 10-16 x .486
*	5303271648	Screw, wafer hd sq dr, 8-18AB x 0.5
*	5303285179	Screw, wafer head, 8-32T x 0.500, black

TOP/DRAWER

POS. NO	PART NO.	DESCRIPTION
1	316110201	Carriage, low broil
2	316236401	Liner, low broil
2A	316110800	Shield, broiler
2B	316237600	Shield, low broil, top
4	316231211	Panel, drawer, white
5	316129100	Fastener, push-in nut, nylon, spacer
9	316081900	Pan, broiler
10	316082000	Insert, broiler pan
13	316111502	Glide, low broil, chassis
13A	316111600	Glide, low broil, inner
13B	316111501	Glide, low broil, outer
16	316104301	Main Top, white
17	316066900	Rod, maintop support
18	08067747	Bracket, hinge, main top RH
18A	08067746	Bracket, hinge, main top LH
20	316055800	Grate, (4)
25	316104500	Cover, vent, chrome
39	316019512	Handle, drawer, black
85	316115600	Rack, low broil
*	316021105	Screw, hex head cup pt, 8-18 x 0.375, black
*	316021108	Screw, cup pt, 8-18 x 0.375, chrome
*	316021110	Screw, 8-18 x 0.5, black
*	316021120	Screw, shoulder head, 8-18 x 5/8, (2), square drive

DOOR




L24D0022

DOOR

POS. NO	PART NO.	DESCRIPTION
6	316222705	Shield, wool, oven door
7	316236801	Insulation, oven door
9	316230615	Liner, oven door
10	316001009	Screw, waf hd sq, 10-24 x 1.88, (2), handle mtg
10B	316008401	Washer, 3/4 OD x 1/4 ID, steel
12	316239700	Seal, oven door
13	316202603	Panel, oven door, white
39	316020204	Handle, door, black, oven
49	316137003	End Cap, handle, black, (2)
60B	316021110	Screw, 8-18 x 0.5, black
*	316433600	Label, anti-tip
*	5303271648	Screw, wafer hd sq dr, 8-18AB x 0.5
*	5303285179	Screw, wafer head, 8-32T x 0.500, black

WIRING SCHEMATIC



WIRING DIAGRAM

