




Electrolux

Factory Parts Catalog

Product No.	E36GC65ESS
Series	36" gas
Color	stainless
Market	North America
Wiring Diagram	WE36GC65ESS
Owner's Guide	5995426235
Installation Instructions	5995426250

Electrolux

ELECTROLUX HOME PRODUCTS, INC.
P.O. Box 212378
Augusta, GA 30917


Publication No.
5995431284
05/03/11
(EN/SERVICE/ECL)
377

36" GAS COOK-TOP RANGE

Model No.
E36GC65E

Copyright © 2005 Electrolux Home Products, Inc.
All rights reserved.


COOK TOP



ME36GC65ESS

COOK TOP

POS. NO	PART NO.	DESCRIPTION
1	5304446037	Grate, burner, (2)
1A	5304446099	Grate, burner, center
2	5304446100	Maintop, stainless
3	5304446029	Knob, burner, (5)
4	5304446031	Bezel, burner knob, (5)
5	5304446019	Screw, phil TRS, #8-3/8, (10)
6	5304446000	Plate, backing, (5)
7	5304446011	Burner Head Assy, "C", 12500 BTU, (2), w/ignitor
7A	5304446010	Burner Head Assy, "B", 8500 BTU, w/ignitor
7B	5304446012	Burner Head Assy, "D", 14000 BTU, w/ignitor
7C	5304446034	Burner Head Assy, "B", 8500 BTU, 90 deg rear, w/ignitor
8	5304446028	Nut, burner head, brass, (4)
9	5304446101	Rings, burner, set of 5
10	5304446098	Caps, burner, set of 5
11	5304446026	Ignitor Assembly, burner, (4)
11*	5304446002	Jacket, ignitor wire, (4)
12	5304445998	Bracket, assembly, hold down
*	5304446032	Cleaner, stainless steel

BURNER

BURNER

POS. NO	PART NO.	DESCRIPTION
1	5304446084	Tubing Assembly, burner, left front
2	5304446088	Tubing Assembly, burner, left rear
3	5304446092	Tubing Assembly, burner, right front
4	5304446093	Tubing Assembly, burner, right rear
5	5304446019	Screw, phil TRS, #8-3/8, (10)
6	5304446094	Valve Assembly, burner, left front, w/ignite switch
7	5304446095	Valve Assembly, burner, left rear, w/ignite switch
8	5304446096	Valve Assembly, burner, right rear, w/ignite switch
9	5304446097	Valve Assembly, burner, right front, w/ignite switch
*	5304446027	Washer, burner valve, (4)
10	5304446014	Switch, ignitor, (4)
11	5304446023	Screw, ignitor switch, (8)
12	5304446036	Regulator, pressure
13	5304446001	Base, burner, (4)
13A	5304446085	Base, burner, center
14	5304446086	Manifold, assembly, w/valves
15	5304446030	Protector, burner valve, spill
16	5304446017	Bushing, strain relief
17	5304446022	Bumper, snap in, rubber, (4)
18	5304446005	Cord, power supply
19	5304446087	Module, assembly, ignitor spark
19*	5304446018	Hook & Loop, pair, 2" x 3"
20	5304446089	Harness, wiring
21	5304446090	Harness, assembly, ignitor wire
22	5304446021	Screw, phil pan, #8-32 x 1/2, (5)
23	5304446024	Washer, #8 x 7/16 OD, 3/64 t, zinc, (8)
24	5304446015	Nut, hex keps, #8-32, (6)
25	5304446020	Screw, phil pan, #8-3/8
26	5304446016	Washer, nylon
27	5304446091	Valve Assembly, burner, center, w/ignite switch
*	5304446083	Conversion Kit, LP gas
*	5304446025	Tool, burner ring, removal

WIRING DIAGRAM

