


# Care of range hood


**Filters:** For best results, remove and clean aluminum filters often. Filters can be cleaned in a dishwasher or with hot sudsy water.

Do not wash charcoal filters used with non-vented (recirculating) installations. Charcoal filters can be replaced by ordering Kit Part No. 4396273, available from your dealer.




**To remove filters:** Pull the deflector down. Push the handles toward the back of the hood and pull down.

**To reinstall filters:** Insert filters into back of hood; push up into place while pushing back on handles. Release handles.



**Replacing lights:** Use a Phillips screwdriver to remove screw holding the light lens cap. Remove the bulb and replace with a 40W, E17 sfera, 120-volt type bulb. Reinstall light lens.



**Cleaning grease collection cup:** Twist cup counterclockwise to remove. Wash in hot sudsy water. Dry, insert into opening and twist clockwise.

**Exterior surfaces:** Clean with a mild detergent and soft cloth. **DO NOT** use abrasive cleaners or steel wool.

## Warranty

### KitchenAid® Range Hood Warranty

LENGTH OF WARRANTY	KitchenAid WILL PAY FOR
LIMITED ONE-YEAR WARRANTY From Date of Purchase	Labor and any parts of your range hood (except light bulbs and filters) which are defective in materials or workmanship.
KitchenAid WILL NOT PAY FOR	
<p>A. Consumable parts such as light bulbs and filters.</p> <p>B. Service calls to:</p> <ol style="list-style-type: none"> <li>1. Correct the installation of the range hood.</li> <li>2. Instruct you how to use the range hood.</li> <li>3. Replace house fuses or correct house wiring.</li> </ol> <p>C. Repairs when range hood is used in other than normal, single-family household use.</p> <p>D. Pickup and delivery. This product is designed to be repaired in the home.</p> <p>E. Damage to range hood caused by accident, misuse, fire, flood, act of God or use of products not approved by KitchenAid.</p>	

**KITCHENAID AND KITCHENAID CANADA DO NOT ASSUME ANY RESPONSIBILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.** Some states or provinces do not allow the exclusion or limitation of incidental or consequential damages, so this exclusion or limitation may not apply to you.

**This warranty gives you specific legal rights, and you may also have other rights which may vary from state to state or province to province.**

**Outside the United States and Canada, a different warranty may apply. For details, please contact your authorized KitchenAid dealer.**

If you need service, see the "Requesting Assistance or Service" section or call our KitchenAid Customer Interaction Center, 1-800-235-0665 (toll-free), from anywhere in the U.S.A. or Canada.