

# BURNER REMOVAL INSTRUCTIONS

## For Napoleon P600 Model Grills

It is recommended that burner removal be performed by a qualified service person



1. Disconnect the gas supply to the grill. Remove warming rack, cooking grids and sear plates.
2. Remove control knobs from gas valves and disconnect wires from ignitor located on the underside of the control panel.
3. Remove the control panel by first removing the 2-1/4" hex head screws located on the lower front corners of the control panel. Lift the panel upward unhooking it from the front lip of the grill base.
4. Disconnect the gas supply hose from the manifold as well as the rear burner feed tube. Remove the three 3/8" mounting screws from the inside of the grill base then remove the manifold assembly.
5. Remove each of the screws located in the centre back of each U shaped burner. Remove the burner shields. Note: For re-installing, the screw can be started through the burner into the back wall before fitting the slotted opening of the burner shield over the screw, behind the burner.
6. Burners can now be removed by pulling each assembly forward then tipping the back of the burner up while pulling the burner out of the ports in the front of the base. Reverse this procedure to re-install ensuring that the burner carryover ports are on the underside of the burners.
7. Re-instill the manifold ensuring that the burners fit over the valve ends. Re-connect the rear burner feed tube and the gas supply hose. Turn on the gas supply. Then check all joints for leaks using a 50/50 soap and water mixture. (See leak testing instructions in the manual.)
8. Reassemble all remaining components.

Ensure that the valve properly enters the mouth of the burner.

