







GENESIS[®] SPIRIT[®]

ADDENDUM: Attach Wires to the PRE-INSTALLED IGNITER MODULE



Disregard igniter module (a) in step illustration.
The igniter module has been installed at the factory.



Connect wires to the ignition module on the underside of the control panel. Install AAA Battery and igniter button.

