







Position of exploded view	Code	Name	Qty
1001	673000900249	External pipe	1
1002	673001500005	O Ring I 31.5X3.55	1
1003	673001800364	Guide casing	1
1004	673001600021	External pipe nut	1
1005	673001900016	Water dispenser	1
1006	673000300077	Upper sprayer	1
1007	673000900195	Upper sprayer pipe	1
1016	673002500047	Micro filter	1
1017	673001600022	Sump nut	1
1018	673001500016	Sump gasket	1
1019	673000700087	Sump	1
1022	673000900075	PVC hose	1
1025	672001200046	board for float support	2
1027	674000600082	Drain pump	1
1036	672000700029	Clamp 14.5×1.8	1
1039	673000900186	Drain hose	1
1043	674000200025	Inlet valve	1
1064	670400051618	Lower sprayer	1
1065	673001200027	Lower sprayer connection assembly	1
1070	674000600053	Washing pump	1
1076	673000900139	PUMP HOSE & CLAMPS	1
1086	674001100033	Heating elements	1
1088	673001600024	Water inlet nut	1
1089	673001500019	Water inlet gasket	1
1090	674000900026	THERMOSTAT 90°C	1
1091	673002600035	Water inlet	1
1092	673006500011	Water inlet cover	1
1093	674000900038	Sensing device	1
1113	673002500044	plane filter	1
1114	673001300137	Scran collection	1
1115	674000300076	Pressure switch 140/120	1
1117	674000300095	pressure switch assembly for heating elements	1
2001	673002000084	Door edge guard piece	2
2002	672002200177	Inner door	1
2004	672001700002	Dispenser bracket	2
2005	674000800047	Dispenser	1
2006	674000100743	Wiring harness	1
2007	675000200023	Inner door foam	1
2008	672000500006	Ring Φ6	4
2009	672001400019	Left hinge	1
2010	672001200012	Dowel	2
2011	672001400020	Right hinge	1
2012	672001300023	Door gemel assembly	1
2013	672000100000	Door spring	2
2014	672001100001	Door spring bolt	2
2017	672001800329	Outer door	1

2018	673000450954	Control panel	1
2023	673001800136	Handle assembly	1
2024	674010030000	door switch	1
2027	674000300065	Power switch	1
2030	673006000017	Handle cover	1
2034	674001001149	Control board	1
2036	673002400190	Control board box	1
2046	673001600034	RING NUT W/GASKET	1
2047	673001700062	GASKET OF VENT	1
2048	673002600034	VENT ASSEMBLY	1
2080	672000100012	button spring	2
2950	673000800482	Power button	1
2951	673005300265	button	2
3003	672002100041	Left frame	1
3006	673001300061	door clamp	1
3007	672001400039	Door lock	1
3009	672001500304	Upper front crosspiece	1
3010	673001700078	Tank gasket	1
3011	672002100042	Upright right assembly	1
3013	673001300102	Upper basket cup holder	4
3014	673002200080	Cutlery basket	1
3017	672000800342	Lower basket	1
3018	672000800336	Upper basket	1
3019	675000200011	TUB INSULATION	1
3021	673001300044	Rail block	2
3022	672001700005	Rail	2
3023	673001400056	Rail support assembly	4
3024	673001100055	Washboard	1
3025	672002300008	Adjustable foot	4
3026	672000200019	Feet support assembly	2
3027	672001500027	Lower front crosspiece	1
3032	673001700010	Tank band bracing block	2
3033	672001500019	Lower rear crosspiece	1
3035	673002200079	Measurable spoon	1
3050	673001300012	Top board hook	4
3070	672001200042	JUNCTION BOX I	1
3071	672001200027	JUNCTION BOX II	1
1071+1072	672000200054	Washing motor support	1
1074-a	673000900140	Connect hose a	1
1074-b	673000900182	Connect hose b	1
1086-a	673002100002	HEATING ELEMENTS CASING	2
1090-a	673001400120	THERMOSTAT BRACKET	1
C5004	673006200004	rinsing agent cup	1
OTK 175	672000700004	OTK 175	1
OTK 310	672000700001	OTK 310	6
OTK 396	672000700007	OTK 396	1