


# EXPLOSION VIEWS & PARTS LISTS

## 1.1.1 BCA184BG Exploded View



### 1.1.2 BCA184BG part list

Item	Spare parts Name	Quantity(PCS)
1	Legs	2
2	Bottom hinge	1
3	Cabinet base (Left)	1
4	Bottom block	1
5	Cabinet base (Right)	1
6	Glass door	1
7	Door gasket	1
8	Knob	1
9	Sensor base	1
10	Screws for the evaporator	3
11	Evaporator	1
12	Door shaft	1
13	Cabinet liner	1
14	Drainage pipe	1
15	Upper hinge cover	1
16	Screw for the upper hinge	1
17	Upper hinge	1
18	Upper hinge bracket	1
19	Cabinet	1
20	Condenser	1
21	Plastic sheet	2
22	Back cover	1
23	Defrosting tray	1
24	Thermostat	1
25	Screw for the thermostat	1
26	Thermostat cover	1
27	Screw for the thermostat cover	1
28	Compressor	1
29	Screw for the compressor	1
30	Spacer for the compressor	1
31	Vibration free rubber	4
32	Compressor base	1
33	Screws for compressor base	4