



SERVICE MANUAL FOR PFRM920W

Item no	Description	Factory part no	Quantity
1	UPPER HINGE COVER	C0507.1-1	1
2	UPPER HINGE ASSEMBLY	C0507.1.3	1
3	BOLT	GB29.2	6
4	LAMP SWITCH 115V/60HZ	B9911.4.1.1	1
5	LAMP GUARD	C0817.4.2-1	1
6	LED LAMP	C0817.4.2	1
7	POTENTIOMETER	C0817.4.8	1
8	AIR VOLUME ADJUSTMENT BAR	C0817.1-4	1
9	THERMOSTAT KNOB	C0817.4-3	1
10	REFRIGERATOR AIR ROAD	C0817.1-2(A1)	1
11	REFRIGERATOR AIR ROAD PANEL	C0817.1-20	1
12	MIDDLE HINGE ASSEMBLY	B0539.1.2	1
13	BOLT ASSY OF MIDDLE HINGE	B0424.1-6	2
14	FAN MOTOR PROTECTING COVER	C0817.4-1(A1)	1
15	FAN MOTOR	C0817.4.5	1
16	MOTOR UPPER SHOCK ABSORPTION GASKET	C0817.1-11	1
17	MOTOR BOTTOM SHOCK ABSORPTION GASKET	B0543.4.25-3	1
18	FAN SUPPORT	C0817.4-2	1
19	FAN BLADE	BCD-198W.4.4-3	1
20	EVAPORATOR ASSY	C0817.3.2	1
21	DEFROST SENSOR	C0817.4.6	1
22	THERMAL CUTOFF	C0472.4.4/B	1
23	DEFROST HEATER	C0817.4.3	1
24	FREEZER AIR ROAD PANEL	C0817.1-5	1
25	REFRIGERATOR SHELF	C0817.5-1	3
26	REFRIGERATOR DOOR UPPER RACK	C0507.5-9	1
27	CAN RACK(I)	C0817.5-4	1
28	REFRIGERATOR DOOR MIDDLE RACK	C0507.5-10(B1)	1
29	CAN RACK(II)	C0817.5-6	1
30	BOTTOM RACK	C0817.5-2(A1)	1
31	VEGETABLE BOX	B0206.5-2	2
32	WIRE SHELF	C0817.5-5	1
33	FREEZER DRAWER	C0817.5-3	1
34	REFRIGERATOR DOOR GASKET	C0817.2.3	1
35	FREEZER DOOR GASKET	C0817.2.4	1
36	BUSH	BCD-181C.2.1-4B	2
37	REFRIGERATOR FOAMED DOOR	F0907.2.1	1
38	DOOR STOPPER	B0376.2-1	1
39	SCREW	QHBT-022	4
40	DOOR STOPPER (LEFT)	C0507.2-1	1
41	FREEZER FOAMED DOOR	C0817.2.2	1
42	DOOR STOPPER	BCD-185E.2.3-2B	1
43	BOTTOM HINGE ASSY	C0507.1.4	1
44	ADJUSTMENT FOOT	B0501.1-2	2
45	COMPRESSOR PLATE	C0507.1.2-1	1
46	COMPRESSOR	HY60YHUR	1
47	FILTER	Q/MLKT-211	1
48	COMPRESSOR BACK COVER	C0817.1-14	1
49	DRAIN TRAY	C0507.1-10	1
50	WATER SEAL	C0817.1-12	1
51	TERMINAL BLOCK ENCLOSURE	C0507.4-2	1
52	CONTROL PANEL	C0817.4.1	1
53	POWER CORD 115V/60HZ	Q/MLKT-138A/H1.CB3W.T2	1
54	TEMPERATURE SENSOR	C0817.4.7	1