

## **Reversing the door**

- 1. Using a sharp object pry out the two plug buttons on the top of the unit. Save the plugs for later use.**
- 2. Remove the upper hinge cover.**
- 3. Remove the two Phillips screws that connect the upper hinge to the cabinet.**
- 4. Carefully lift the door, placing it on a padded surface to avoid scratching.**
- 5. Tilt the unit back and remove the screws on the lower hinge.**
- 6. Remove the stationary leg and attach to the opposite side.**
- 7. Attach the lower hinge on the opposite side.**
- 8. Place the door on the lower hinge making sure that the hinge pin goes into the door bushing.**
- 9. Place the upper hinge cover on the top of the door and loosely place the screws in the top of the cabinet.**
- 10. Line up the door and tighten the screws.**

**(Check the seal around the door for air gaps. Use a hair dryer to heat the gasket and expand the seal to fill in the gaps)**