



AVANTI parts for WC4800C

Item	Parts No.	Description	Qty
1	DG11-4	Dry filter	1
4	DG2-11	Power cord	1
5	DG13-1	Water tray	1
6	DG7-23	Exterior fan	1
7	DG19-3	Fan cover	1
8	DG14-56	Exterior Fan Bracket	2
9	DG1-71	Compressor	1
13	DG22-1136	Power supply bracket enclosure	1
14	DG6-1003.2	Transformer	1
15	DG3-1070	PCB and display panel	1
18	DG13-325	LED cover	8
19	DG3-1069-W	LED light	8
20	DG14-1072-R-B	Upper Hinge	1
22	DG12-1	Evaporator	1
23	DG8-501	Thermo-sensor probe	2
24	DG7-3.1	Evaporator fan	1
26	DG13-1063	Charcoal filter	1
27	DG19-6	Fan cover	1
28	DG3-1003.3	Top LED light (9 LEDs)	1
29	DG13-1082	Circuit Board Housing	1
30	DG13-1083	Display Board Bracket	1
31	DG20-1081	Control panel film	1
32	DG22-1194	Control panel Bracket	1
33	DG14-1014.2	Door axis	1
34	DG15-1077	Iron bracket for vertical bott	1
35	DG22-1196	Lower Door Insert	1
36	DG15-1078	Fixed wood strip	1
38	DG23-1105	Door	1
39		Door gasket	1
40	DG15-1076.3	Bottom wire shelf	1
41	DG15-1076.2	Small wire shelf	2
42	DG15-1076.1	Middle wire shelf	1
43	DG15-1076	Big wire shelf	3
44	DG13-7	Shelf stopper	14
45	DG9-1002	Light switch	1
46	DG14-105.1	Lock	1
47	DG13-1084	Bottom grille	1
48	DG14-1073-R-B	Right Lower Hinge	1
49	DG13-1092	Leg	4
51	DG14-1073-L-B	Left Lower Hinge	1
52	DG12-15	Condenser coils	1