# FRIGIDAIRE.

# Freezer



#### Manual Defrost 5 Cu. Ft. Chest

#### **Product Dimensions**

Height (Including Lid)	32-1/2"
Width	28-1/2"
Depth	22"

#### More Easy-To-Use Features

#### Manual Defrost

**Defrost Water Drain** Use the drain to conveniently remove water during defrosting.

Available in:

White (W)

### **Signature Features**

#### Store-More<sup>™</sup> Removable Basket

Stay organized with our removable basket that can hold small frozen items, or be removed if you have large items that need to be stored.

#### **Power-On Indicator Light**

Know at a glance that your freezer is working.

#### Adjustable Temperature Control

Select the correct temperature for your needs.


#### **Color-Coordinated Handle**

## **FRIGIDAIRE**

F	Freezer		
FFFC05M1QW	5 Cu. Ft. Chest		

Features	
Defrost	Manual
Adjustable Temperature Control	Yes
Interior Lighting	
Store-More™ Removable Baskets	1
Food Organization System	
Defrost Water Drain	Yes
Lid Handle	Yes
Lock with Pop-Out Key	
Power-On Light	Yes
Certifications	
CSA Rating	Household
Specifications	
Total Capacity (Cu. Ft.)	5.1
Annual Energy (kWH)	220
Annual Energy Cost (.1065/kWH)	\$26
Power Supply Connection Location	Right Bottom Rear
Voltage Rating	120V/60Hz/5A
Connected Load (kW rating) @ 120 Volts1	.6
Amps @ 120 Volts	5
Minimum Circuit Required (Amps)	15
Shipping Weight (Approx.)	85 Lbs.

<sup>1</sup>An electrical supply with grounded three-prong receptacle is required. The power supply circuit must be installed in accordance with current edition of National Electrical Code (NFPA 70) and local codes & ordinances.



Тор	) View	Recessed	outlet
		<u>*////*//////</u>	
*	<ul> <li>allow 3" minim</li> </ul>	air circulation, num clearance on h 1" at bottom	* *


NOTE: For planning purposes only. Always consult local and national electric codes. Refer to Product Installation Guide for detailed installation instructions on the web at frigidaire.com.



Product Dimensions	
A-Height (Including Lid)	32-1/2"
B-Width	28-1/2"
C-Depth	22"
Height with Lid Open 90°	55-5/16″

Accessories information available on the web at **frigidaire.com** 

**FRIGID**AIRE USA • 10200 David Taylor Drive • Charlotte, NC 28262 • 1-800-FRIGIDAIRE • frigidaire.com CANADA • 5855 Terry Fox Way • Mississauga, ON L5V 3E4 • 1-800-265-8352 • frigidaire.ca FFFC05M1Q 04/14



#### **Chest Freezer Specifications**

- Product Shipping Weight (approx.) 85 Lbs.
- An electrical supply with grounded three-prong receptacle is required. The power supply circuit must be installed in accordance with current edition of *National Electrical Code (NFPA 70)* and local codes & ordinances.
- Voltage Rating -120V/60Hz/5 Amps
- Connected Load (kW Rating)@120 Volts = 0.6 kW
- Amps@120 Volts = 5 Amps
- Always consult local and national electric codes.
- For adequate air circulation, allow 3" minimum clearance on all sides with 1" at bottom.
- $\,$  Locate where surrounding air temperature will not exceed 110° F, to ensure optimum performance. (Temperatures 32° F and below will NOT affect operation.)
- All bottom corners of unit MUST rest firmly on solid level surface of hard material, same height as flooring. Surface must be strong and stable enough to support unit when fully loaded.
- Equipped with adjustable leveling legs to ensure unit is level, which is required in order to function properly.
- Note: For planning purposes only. Refer to Product Installation Guide on the web at frigidaire.com for detailed instructions.



USA • 10200 David Taylor Drive • Charlotte, NC 28262 • 1-800-FRIGIDAIRE • frigidaire.com CANADA • 5855 Terry Fox Way • Mississauga, ON L5V 3E4 • 1-800-265-8352 • frigidaire.ca FFFC05M1Q 04/14