

RM3100WT, RA3101BT, AND RA3103SST

No.	Parts code	Description of Spare Part
1	10011011	Cabinet
2	20022149	Upper hinge assembly
4		Top cover clip
6	20016014	Top cover
7	20016012	Upper door gasket
8	Subject to unit color	Upper door
9	Subject to unit color	Lower door
10		Top cover clip
11	20016008	Upper door bar
12	20020965	Short curved bar
13B	20011610	Crisper Box (emeral green)
14B	10200572	Crisper box cover
16	20021052	Compressor support base
17		Power supply cord
20	20050008	Earthing wire of compressor
21	B25H5B	Compressor
22	20050009	Connecting wire of compressor
23	20060010	Process tube
24	20060046	Connecting tube (short)
26B	20060048	Drier filter (for R134a)
28	20014438	Base of wire box
29	20014437	Terminal cover
30	20010123	Long Adjustable Foot
34	20010111	Short Adjustable Foot
35	20021371	Lower Door Hinge Assembly
36	10201976	Shelves of fridge (glass)
37	20011051	Lamp cover
38B	20010045	Lamp Bulb (E14,110V)
39	20010024	Knob
40	20010216	Thermostat cover
41	20060719	Thermostat
43	20050016	Door switch
44	20012230	Middle hinge bottom plate
45	20021249	Middle hinge
48	20020966	Short straight bar
49	20020105	Drink bottle holder bar
50	20022196	Drink bottle holder
51	20016013	Lower door gasket
52	20010021	Lower door right aid-closer
53	20010384	Lower door left aid-closer
54	20010068	Right limit block of door
55	20010371	Left limit block of door

