


MICROWAVE OPTIONS

Automatic cooking

There are 17 microwave cooking options, including popcorn, reheating, cooking and defrosting.

- 1 Press the desired pad.
- 2 Press UP or DOWN arrows to select the desired food.
- 3 Follow the directions in the display. Example: enter weight.
- 4 Press START.



Popcorn	Reheat	Cook	Defrost
Regular	Beverage	Baked potatoes	Bone-in poultry
Regular light	Casserole	Fresh vegetables	Boneless poultry
Snack	Dinner plate	Frozen entrees	Ground meat
	Fresh rolls/muffins	Frozen vegetables	Steaks / chops
	Soup	Ground meat	

GRILL, ROAST, BAKE

Manual speed cooking

- 1 Press GRILL, ROAST or BAKE pad.
- 2 Enter time.
- 3 Press START. For GRILL, preheat will start automatically. No food in the oven until preheat is over.



You can change the temperature for ROAST and BAKE. See Use and Care Guide for the details.

CONVECTION

Manual cooking

- 1 Press PREHEAT, if desired. If no preheat is desired, press CONVECTION.
- 2 Press the desired temperature.
- 3 Enter time.
- 4 Press START. Preheat will start, if it was chosen.



MICROWAVE COOKING

Manual cooking

- 1 Enter time.
- 2 Press START.



You can change the power level. See Use and Care Guide for the details.

TCADHB063M/RRO

TOUCH GUIDE

For more complete information and safety precautions, refer to your Use and Care Guide.

COOKS FASTER Bakes, grills and roasts up to five times faster.

COOKS EASIER Over 200 preprogrammed foods and recipes taste great and are easy to make.

COOKS BETTER High speed hot air circulation with microwave assistance.

MANUAL SPEED COOKING

Use these manual settings when preparing foods not in BASIC COOK or RECIPES.

GRILL

is ideal for foods that cook quickly with high heat. Use high or low rack and splash guard. Setting has automatic preheat. Follow directions in the display. Watch carefully to prevent over cooking.

ROAST

is ideal for larger cuts of meat and poultry. No turnover is required. Use low rack and splash guard. Reduce usual roasting times by 33 to 50 percent.

BAKE

is ideal for foods that need to be baked more than 20 minutes and can be baked on one level on the low rack. Reduce usual baking times by 25 to 33 percent.

AUTOMATIC SPEED COOKING

BASIC COOK

has 84 preprogrammed foods that are grilled, baked or roasted perfectly.

RECIPES

has 100 preprogrammed recipes that are quick, easy and delicious. Use the Viking High Speed Convection Oven Cookbook for step-by-step instructions.

DISPLAY

Words will light in the display to indicate features and cooking instructions.

POWER LEVEL

Press POWER LEVEL repeatedly to choose desired microwave power level.

NUMBER PADS


The 10 number pads are used for entering time, time of day, weight, quantity or temperature.

TIMER/CLOCK

Use to set time of day or kitchen timer.

STOP/CLEAR

During programming, press STOP/CLEAR once to return to the time of day. During cooking, press STOP/CLEAR once to stop cooking or twice to cancel the cooking program.



MANUAL CONVECTION

CONVECTION

Use CONVECTION to cook/bake foods using package/recipe times and temperature. No changes are necessary.

PREHEAT

When preheat is desired, press PREHEAT and follow the instructions in the display.

AUTOMATIC MICROWAVE OPTIONS

There are 17 microwave cooking options.

POPCORN

is for microwave popcorn and has 3 options: regular, regular light and snack.

REHEAT

has 5 options : beverage, casserole, dinner plate, fresh rolls/muffins and soup.

COOK

has 5 options : baked potatoes, fresh vegetables, frozen entrees, frozen vegetables and ground meat.

DEFROST

automatically defrosts : bone-in poultry, boneless poultry, ground meat and steaks/chops.

UP DOWN ENTER

Use UP and DOWN arrows to see the food choices in the display when using BASIC COOK, RECIPES and MICROWAVE OPTIONS.

Use ENTER when using BASIC COOK or RECIPES number. For example, BASIC COOK, 1 and ENTER to select Frankfurters.

HELP

provides 4 features which make using your oven easy.
1.Child lock **2.Audible signal elimination**
3.Auto start **4.Refresh cycle**
 When HELP is flashing, press HELP for important information.

START

Whenever the oven is ready to cook, simply press START.

ADD-A-MINUTE

Press ADD-A-MINUTE for 1 minute of cooking at 100% power. To extend time during cooking in multiples of 1 minute, press ADD-A-MINUTE repeatedly.

