



MINIBARS

**Models MB24L
MB34L
MB44L
MB25LGL**

Instruction Manual

**FELIX STORCH, INC.
Summit Appliance Division
770 Garrison Avenue
Bronx, New York 10474
www.summitappliance.com**

Thank you for using our product. This easy-to-use manual will guide you in getting the best use of your appliance.

Model number

Remember to record the model number and the serial number, which can be found on the label inside the cabinet.

Serial number

Date of purchase

Staple your receipt to your manual. You will need it to obtain warranty service.

IMPORTANT SAFEGUARDS

Please read all of these instructions before using this appliance. When using this appliance, always exercise basic safety precautions, including the following:

1. Use the appliance only for its intended purpose as described in this manual.
2. The appliance must be properly installed in accordance with the installation instructions before it is used. See grounding instructions in the *Installation* section.
3. Never unplug your cooler by pulling on the power cord. Always grasp the plug firmly and pull straight out from the outlet.
4. Repair or replace immediately all electric service cords that have become frayed or otherwise damaged. Do not use a cord that shows cracks or abrasion damage along its length or at the plug or connector end.
5. Unplug your appliance before cleaning or before making any repairs.

NOTE: If for any reason this product requires service, we strongly recommend that a certified technician perform the service.

6. If your old refrigerator is not being used, we recommend that you remove the doors. This will reduce that possibility of danger to children.
7. The appliance should not be recessed or built into a cabinet. It is designed for free-standing installation only.
8. Do not operate this appliance in the presence of explosive fumes.

DANGER! *Risk of child entrapment*

Before you throw away your old cooler, take off the doors. Leave shelves in place so that children may not easily climb inside.

– SAVE THESE INSTRUCTIONS –

INTRODUCTION

Your Minibar operates silently and efficiently to keep beverages cold. To assure proper functioning, please observe the following recommendations:

1. To allow for proper air circulation, the unit should be kept at least 2 cm (approx. 1 inch) away from the wall behind it.
2. Be sure the Minibar is perfectly level.
3. Locate the unit away from direct sunlight. This will save energy and enable the unit to perform at its best.
4. Under NO circumstances should the top plastic grid be covered. This would prevent the circulation of warm air.

When unpacking the Minibar, check that nothing is missing or damaged. Damage in transit must be reported immediately to the carrier.

INSTALLATION

The best refrigerating performance using the least power consumption is achieved by placing the Minibar away from sources of heat (e.g., oven, radiator) and out of direct sunlight. Use a spirit level to ensure that the unit is perfectly level.

CAUTION: The Minibar is designed to stand free and not be built into or under anything. Place the Minibar so that the circulation of air around the absorber at the back is not obstructed. The rear ventilation grid must always be uncovered. The rear of the unit should be at least 2 cm (~1 inch) clear of a wall.

Electrical Connection:

- This Minibar requires an electrical connection of 115V/60Hz with a grounded, three-prong socket.
- The unit is equipped with a three-prong plug and is grounded to eliminate electrical hazards. In order to make it effective, the unit must be plugged into a grounded electrical outlet.
- Do not use an extension cord.

Door Reversal:

The door for each Minibar (except model MB44L) is reversible; that is, it can open from either the left or the right, whichever is more convenient. To reverse the door opening, unscrew the hinge plates, lift off the door, switch the hinge plates to the other side and replace the door, making sure it is absolutely level before the final tightening of the screws.

OPERATION

To Start the Minibar:

Plug in the unit . Be sure the electrical supply is 115V AC and 60 Hz (normal household voltage).

The temperature control (thermostat) is located inside the Minibar on the rear wall. Turn the thermostat knob clockwise to its highest (i.e., coldest) setting, position **6** or **7**. After several hours, reset the thermostat to a medium setting, and the unit is ready for use.

Defrosting:

The Minibar defrosts itself automatically, but if frost builds up, you can always defrost the unit manually by turning the thermostat to OFF and leaving the door open until the frost has melted. Remove the contents and shelves and use a soft, clean cloth to dry the interior of the unit thoroughly before once again turning on the thermostat.

CLEANING AND MAINTENANCE

Before putting the unit into service, it is advisable to clean the Minibar inside and out with a solution of mild, non-abrasive detergent in lukewarm water. Then rinse it with tap water and dry it thoroughly. Do not use soap or harsh, grainy cleaning agents under any circumstances. Clean the shelves in the same way.

The rubber door gasket should never be exposed to oil or grease. It can be kept soft with an application of talcum powder.

To keep the Minibar working at its best, the unit should be cleaned regularly, as described above.

Do not operate the Minibar if the power cord is frayed or damaged. Call your dealer for information on obtaining a new cord.

TROUBLESHOOTING

You can solve many common refrigeration problems easily, saving you the cost of a possible service call. Try the suggestions below to see if you can solve the problem before calling a service technician.

TROUBLESHOOTING GUIDE

Problem	Possible Cause
Appliance does not operate.	Not plugged in. The circuit breaker has tripped or fuse has blown. The Temperature Control Knob is turned off.
Appliance does not get cold enough.	Ambient temperature is too high. Thermostat should be set higher. Door is not completely closed.
Vibrations	Check to be sure that the unit is level.
The door will not close properly.	The appliance is not level. The door was reversed and not properly re-installed. The gasket is dirty. The shelves are out of position.

If your appliance shows symptoms other than those described above, or if you have checked all items listed as the cause and the problem still exists, then call SUMMIT® Customer Service at

1-800-932-4267

ONE-YEAR LIMITED WARRANTY

Within the 48 contiguous United States, for one year from the date of purchase, when this appliance is operated and maintained according to instructions attached to or furnished with the product, warrantor will pay for factory-specified parts and repair labor to correct defects in materials or workmanship. Service must be provided by a designated service company. Outside the 48 states, all parts are warranted for one year from manufacturing defects. Plastic parts, shelves and cabinets are warranted to be manufactured to commercially acceptable standards, and are not covered from damage during handling or breakage.

ITEMS WARRANTOR WILL NOT PAY FOR:

1. Service calls to correct the installation of your appliance, to instruct you how to use your appliance, to replace or repair fuses or to correct wiring or plumbing.
2. Service calls to repair or replace appliance light bulbs or broken shelves. Consumable parts (such as filters) are excluded from warranty coverage.
3. Damage resulting from accident, alteration, misuse, abuse, fire, flood, acts of God, improper installation, installation not in accordance with electrical or plumbing codes, or use of products not approved by warrantor.
4. Replacement parts or repair labor costs for units operated outside the United States.
5. Repairs to parts or systems resulting from unauthorized modifications made to the appliance.
6. Expenses for travel and transportation for product service in remote locations.
7. The removal and reinstallation of your appliance if it is installed in an inaccessible location or is not installed in accordance with published installation instructions.

DISCLAIMER OF IMPLIED WARRANTIES - LIMITATION OF REMEDIES

CUSTOMER'S SOLE AND EXCLUSIVE REMEDY UNDER THIS LIMITED WARRANTY SHALL BE PRODUCT REPAIR AS PROVIDED HEREIN. IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO ONE YEAR. WARRANTOR SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, OR LIMITATIONS ON THE DURATION OF IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS, SO THESE EXCLUSIONS OR LIMITATIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE.

FELIX STORCH, INC.
770 Garrison Avenue
Bronx, NY 10474
Phone: (718) 893-3900
Fax: (718) 842-3093
www.summitappliance.com

SUMMIT

For parts and accessory ordering,
troubleshooting and helpful hints, visit:
www.summitappliance.com/support