




PRODUCT MODEL NUMBERS

EV187NYRV / EL87TRRRV
 EV187NYRS / EL87TRRRS
 EV187NYRQ / EL87TRRRQ

Electrical: A 115 Volt, 60 Hz., AC only 15 or 20 amp fused (or circuit breaker), grounded electrical supply is required. It is recommended that a separate circuit serving only your freezer be provided. Use an outlet that cannot be turned off by a switch. Do not use an extension cord.

Water Supply: Connect the ice maker to a cold water line with water pressure between 30 and 120 psi.


OVERALL DIMENSIONS



Width "C" includes recommended spacing (0.25 in.) between refrigerator and freezer

Model	Depth "A"	Cabinet Height "B"	Width "C"
EV187NYRV / EL87TRRRV	32.0"	67.3"	60.25"
EV187NYRS / EL87TRRRS	32.0"	67.3"	60.25"
EV187NYRQ / EL87TRRRQ	32.0"	67.3"	60.25"

LOCATION REQUIREMENTS



Allow at least 3 in. (7.5 cm) of air space at the top and on both sides of the appliances with 1/4 in. (6.5 mm) between the freezer and refrigerator. Allow 1 in. (2.5 cm) between the back of the appliances and the wall. If the appliances are to be against a side wall, leave extra space on the hinge sides so the door can open wider.

IMPORTANT: Do not install the appliances near an oven, radiator, or other heat source, nor in a location where the temperature will fall below 40°F (5°C).